


TENSIONER INSTALLATION INSTRUCTIONS

Plymouth, MA 02360 - www.atlantisrail.com

CAUTION: USE WORK GLOVES TO PROTECT YOUR HANDS AGAINST INJURY BY CABLE



INSTRUCTIONS

- 1. Mount base to a flat surface using three (4mm) #8 stainless steel fasteners.
- Extend Threaded Stud 3/4" for a section of 20 feet or less and extend an additional 1/4" for every 10 feet thereafter. Maximum recommended cable span is 48 feet.
- 3. Insert cable into Receiver Cone, Wedge and Spacer until it is fully seated in the Threaded Stud.
- 4. Thread Cone Assembly onto the Threaded Stud. Tighten until threads are no longer visible (if possible) and Receiver Cone is tight.
- 5. TO TENSION: Hold hex flats on Threaded Stud with a wrench. Place a wrench on hex flats of Tensioner Body and rotate Tensioner Body as needed. Tension cable equally from both ends of each cable span.
- 6. Tighten Lock Nut to secure tension.
- 7. Add "Non-Acidic" Silicone Sealant to open tip of Receiver Cone in harsh environments per additional instructions.

